

# 4 X 4 POST ADAPTER ASSEMBLY

- 1) INSERT LONG NARROW END OF ADAPTER INTO BOTTOM OF PERMIT BOX. **PUSH** ADAPTER ALL THE WAY IN UNTIL HOLE IN ADAPTER LOCKS IN PLACE.
- 2) PLACE PERMIT BOX AND LARGE END OF ADAPTER OVER TOP OF 4 X 4 POST (POST NOT SUPPLIED) SECURE WITH DESIRED NUMBER OF SCREWS

